

**TYPE S MORTAR MIX** is a quality blend of fine masons sand, portland cement and lime. It is used to build brick, stone and block walls, and can be used as a stucco scratch and base coat. Roman Mortar Mix is also used to tuckpoint mortar joints. Roman Mortar Mix is designed to exceed the specifications of ASTM C 387 and C 270 for Type S Mortar/Stucco.

## **COMPRESSIVE STRENGTH:**

28 day 1,800 psi (12 MPa) Water Retention 75%

### **MIXING:**

One 80 lb. (36.4 kg) bag will require up to 4 quarts (3.7 L) of water. Thoroughly mix the contents of the bag with the water, adding the a little at a time if the mix is too stiff. *Adding too much water will weaken the mix and may cause cracking in the surface.* 

## FINISHING:

Butter the ends of the brick or block with the mortar and place into a bed of mortar. Level while gently tapping into place. When used in tuckpointing, after compaction into the joint, allow the fresh mortar to set before striking with a jointer tool.

# **CURING:**

Keep the placed material damp in hot weather conditions to aid curing. Protect the mortar from freezing for at least 24 hours after placement.

# **COVERAGE:**

One 80 lb. (36.4 kg) bag will lay about 44 standard brick or 16 - 8 inch concrete block. One 80 lb. (36.4 kg) will cover about 72 sq. ft. at 1/8 inch thick.

### **ITEM/ UPC:**

# 02033/ 8-99002-00203-3

Revised 11.10.09

SAFETY: Before using this product, read the Material Safety Data Sheet (MSDS). WARNING: Wear protective clothing and equipment as needed. Read specific warnings on the package for inhalation, eye and skin contact. KEEP OUT OF REACH OF CHILDREN.



echnica